


FALCON Update procedure



FALCON– Firmware update procedure (1/3)







- Copy / Paste the FALCON Firmware update file (.czip) **at the root** of a USB Stick (formatted in FAT32).



- Connect the USB Stick with the firmware update file to the FALCON as illustrated on this picture


FALCON – Firmware update procedure (2/3)



FALCON – Firmware update procedure (3/3)



- Note: Your FALCON must be powered during the whole update process: Plug the power supply before starting the update.



- Start the update procedure: it can take several minutes! Please wait for the end of the procedure. Don't disconnect the power supply until the end of the update (back to home screen of the FALCON)